

About your Hot Water Timer Switch


Your Hot Water Timer switch will appear similar to the below pictures. The switch will be set by your GET technician to turn on during solar hours. This will usually be from 10am to 2pm but may vary for each system and household needs.



Used all your hot water and need it to heat outside of solar hours?

If you have used all your hot water you can turn off the Hot Water Timer off and the system will heat as it needs to. Please note when the Hot Water Timer is off it could be heating outside of solar hours and therefore be consuming power from the mains.

1. To override the Hot Water timer switch push the switch to the I position.
2. To turn the timer back on push the switch back to **auto**.



Note: If you are needing to do this regularly please let us know and we can adjust the time your system is heating for.

GreenEnergy 
Technologies

the local experts in affordable energy